

---

## Castle nuts and cotter pins

The example is a rear motor mount bolt, but this will work on any bolts where it is difficult to see the cotter pin hole with the castle nut installed. Scribe a line across the end of the bolt before assembly to help “line up” the castle nut for that darn #%\$@^&%&\* cotter pin.

Dave Westenberger – Colonial Virginia Model A Club



PHOTO BY DAN using Dave's hand

---